Electronic tape feeding system

TAPE DISPENSER

Easy-use equipment for cutting cohesive tape from reel and release it to the operator's hand for the immediate manual banding of coiled tubing or bundles of tubing.



Tecnoideal



TAPE DISPENSER

Tape Dispenser can be customized to accept 1/2" or 1" tape.



GENERAL FEATURES

- If using automatic feeder, when one piece of tape is removed, the unit will automatically feed and cut the next piece at the present length.
- The tape length is easily seen on the LED display, and operation is simple press the CM key or MM key to set the length (Setting limit : 20 mm to 9999 mm)
- If a piece of long tape is needed, press FEED key for desired length, then press CUT key to cut.
- The blade unit can be removed and replaced easily. (Tape jamming is also easily fixed by removing the blade unit).

Product Code 98124